


NETWORK VIDEO MANAGEMENT SOFTWARE (NVMS) SETUP GUIDE


START HERE

IMPORTANT:

Please note that a graphic acceleration card is required for video streaming and playback. We recommend NVIDIA GeForce series / ATI Radeon series or any other similar function video card.




Connection Diagram



EASY SETUP STEP 1 - 2 - 3


- 1 Insert the NVMS installation disc in your computer and run setup.exe. Simply follow the instruction to install.



- 2 After installation, there will be a new icon "NVMS" on your desktop screen.



Double click the icon to login.
Default login: admin
Default password: admin



- 3 Once successfully logged in, NVMS will automatically detect the IP camera installed in the same network. This process normally take about 3 minutes or more. Once its detected, simply double click the IP address, the video will show up on the video screen.



Need More Help?

For information about features, please refer to the user manual for example settings and definitions. Additional product information can also be found in the Product Manual on the CD. Please feel free to give us a call or simply log on to <http://www.bolideco.com> for more information and support.



BOLIDE
TECHNOLOGY GROUP



Bolide Technology Group
is a ISO 9001:2008 Certified Corporation